EC2B Series Control Boxes (Flameproof & Increased Safety)

Complies with IECEx, ATEX, Ex-CCC, UL/c-UL and TIIS. Ideal for use in factories.

- Corrosion resistant stainless steel enclosure.
- Applicable in areas where explosive gases/steam exist including hydrogen and acetylene, and environments subject to dust (ATEX, IECEx, Ex-CCC).
- Available with a variety of switches/pilot lights and enclosures.
- Available for global applications

Global: IECEx

North America: UL/c-UL Europe: CE/ATEX China: Ex-CCC Japan: TIIS

• Degree of protection: IP65 (IEC 60529), Type4X (UL)

















Specifications

<u>- </u>	
Degree of protection	IP65 (IEC60529), Type 4X (UL)
Housing Material	Stainless steel (SUS304)
Standard Coating *	5Y7/1 (semi gloss) melamine baking (coating thickness: 10 µm) 1-column: Outside coating 2-, 3-, 4-column: Inside and outside coating
Rated Insulation Voltage	600V (with pilot light or ET2A-8PE screw terminal block: 500V) Meter AC input: 300V Meter DC input: 150V
Insulation Resistance	100 MΩ minimum (500V DC megger)
Operating Temperature	-20 to +50°C (no freezing)
Operating Humidity	45 to 85% (no condensation)
Altitude	2000m maximum

- * Special coating, buffing (#400), and special color are possible.
- * Contact IDEC for details.

Explosion protection specifications and certification number

Certification	Explosion Protection	Certification No.
TIIS	Ex de IIC T6	See Page 24
IECEx	Ex db eb IIC T6 Gb Ex tb IIIC T80°C Db (dust)	IECEx PTB 15.0032
ATEX	Ex db eb IIC T6 Gb Ex tb IIIC T80°C Db (dust)	PTB 08 ATEX 1048
UL	Class I, Zone 1 AEx d e IIC T6 Gb Class I Div 2, Groups A, B, C and D	
c-UL	Class I, Zone 1, Ex de IIC T6 Gb	E347230
Without pilot light	Class I Div 2, Groups A, B, C and D	
c-UL	Class I, Zone 1, Ex de IIB T6 Gb	
With pilot light	Class I, Div 2, Groups C and D	
Ex-CCC	Ex de IIC T6 Gb Ex tD A21 IP65 T80°C (dust)	202001230434 8115

IECEx/ATEX/Ex-CCC, UL/c-UL/ IECEx/ATEx, and TIIS Comparison


	IECEx/ATEX/Ex-0		UL/c-UL, IECEx/ATEX certified	TIIS certified
Part No.		EC2B	EC2B-U	EC2B-
Applic	able Enclosure	All enclosures	All enclosures except for 6 Control Units x 4 Column	All enclosures
Moun	ting Style	Wall Mount	Wall Mount	Wall Mount Pole Mount
+	Pilot Light	Yes	Yes (*1)	Yes
D	Pushbutton	Yes (*2)	Yes (*2)	Yes
trol	Emergency Pushbutton	Yes	Yes	Yes
Control Unit	Selector Switch	Yes	Yes	Yes
) e (Key Selector Switch	Yes	Yes	Yes
icat	Meter	Yes Yes		Yes (*3)
Applicable	Buzzer	1	_	Yes
	Variable Resistor			Yes
Reduc	Metric Thread (standard)		NPT Thread (standard)	Pipe Parallel Thread (standard)
Tieddol Golew		NPT Thread/Pipe Parallel Thread	Metric Thread	Metric Thread/NPT Thread
Cable	Lead-in Fitting	— (*4)	- (*4)	Yes (HPN)
Lead-	in Port Plug	— (*4)	- (*4)	Yes (GBE)
Degre	e of Protection	IP65	IP65, TYPE4X (UL)	IP65
Groun	ding Terminal Screw Material	Stainless Steel	Stainless Steel	Brass
eldi	Stranded Wire (mm²)	1.25 to 2.5	1.5 to 2.5	1.25 to 2.5
Applicable Wire	Solid Wire (mm²)	1.2 to 1.6	1.2 to 1.6	1.2 to 1.6
Ap	Solid/Stranded Wire (AWG)	16-14	16-14	16-14

- *1: c-UL explosion protection is different when pilot light is installed.
- *2: Part no. is different from TIIS certified model.
- *3: Part no. of TIIS certified meter is different from the meter certified by other organizations.
- *4: Use fittings and plugs commercially available compliant to the corresponding standards.

Control Boxes (TIIS, IECEx, ATEX, Ex-CCC, UL/c-UL)

Control Box

	1, 2 control units	3 control units	4 control units	5 control units
1-column				
2-column				
3-column				



Control Units

Control Unit	Pilot Light		Pushbutton		
Shape	Round	Flush	Extended	Mushroom	Mushroom (ø40)
Operation	-		Momentary		Push-to-lock, pull or turn-to-reset
Shape					
Illumination color/but- ton color	R (red) G (green) Y (yellow) A (amber) W (white) S (blue) PW (pure white)	B (black) G (gree	en) R (red) W (white)	Y (yellow) S (blue)	R (red)
Part No.	EU2B-YL	EU2B-YB1	EU2B-YB2	EU2B-YB3	EU2B-YBV
Page	15		15		15

Control Unit	Selecto	r Switch	Buzzer (*)	Variable Reducer (*)	Meter
	Knob Operator	Key			_
Shape					
Part No.	EU2B-YS	EU2B-YSK	EC9F-Z	EC9E-R	EU2B-YM/EC9F-M
Page	1	6	16	17	17
<u> </u>					

^{*} Only approved under TIIS standards.

Nameplate/Mounting Hole Plug


		<u> </u>		
Name	Control Unit Nameplate	Marking Plates for Control Unit Nameplates	Emergency Stop Switch Nameplate Sticker	Control Unit Mounting Hole Plug
Shape		HAND OFF AUTO START ON STOP OFF	000	
Part No.	EU9Z-NM	EU9Z-NP	EU9Z-NVS	EU9Z-BP
Page	23	23	23	23

^{*} See page 21 for accessories.

Standard Part No. Development (reference)

The chart below describes the configuration of standard model. See next page for standard model.

For custom order models, contact IDEC for part number, prices, and delivery time. Please use this chart for interpreting part numbers, not for developing part numbers.



Standard control box

- Specify the Part No. when ordering standard control boxes.
- For control unit specifications and part numbers, see pages 13 to 17. For cable lead-in fitting specifications, see page 9. For specifications of control unit nameplate and emergency stop switch nameplate sticker, see page 23.
- If a control unit nameplate or emergency stop switch nameplate sticker is not required on standard control boxes, add "0" after the Part No.

Example: EC2B-1102BF2NC10

Custom assembled control box

- If the required control units, accessories, and cable lead-in fittings are not standard specifications, and if control box nameplate (NP) is required, specify the required specifications on the Specification Sheet on pages 29 to 30.
- TIIS certified models: the model and number of control units that can be installed depend on the size of control box. See page 24 for TIIS certified products and specify the control unit configuration.

Standard and custom assembled control boxes

· Part No. is shown on control boxes as below.

TIIS certified

TIIS certified part no. (see page 24.)

Part No. Example

Wall mount

EC2B-1102BF2NF2 Part No: Part No. on control box: EC2B-1102-F

IECx/ATEX/Ex-CCC certified

EC2B-□□□□-GL

Part No. Example

Part No: EC2B-1102BM3NC3-GL

Part No. on control box: EC2B-1102-GL

UL/c-UL, IECEx/ATEX certified

EC2B-□□□□-U

Part No. Example

EC2B-1102BN2F4-U Part No: Part No. on control box: EC2B-1102-U

• See below for the symbols of control units.

(P): Pilot light

(B): Pushbutton

Emergency stop switch

S: Selector switch/Key selector switch

M: Meter

BZ: Buzzer

🕅 : Variable Resistor

(B): Control Unit Mounting Hole Plug

Control Boxes

1 Control Unit × 1 Column (without wiring) (standard models)

Pushbuttons

Shape/S	ymbol		Mounted Control Units					
E!	31 	1	Flush momentary 1NO contact Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Nameplate OFF Button color (supplied with black, green, red, and white buttons)		
Part No. (IECEx/ATEX/E certified)	(IECEx/ATEX/Ex-CCC		EC2B-1102BM3N□1-GL	EC2B-1102BM3N□2-GL	EC2B-1102BM3N□3-GL	EC2B-1102BM3N□4-GL		
Part No. (UL/c-UL, IECEX/ATEX certified)			EC2B-1102BN2N□1-U	EC2B-1102BN2N□2-U	EC2B-1102BN2N□3-U	EC2B-1102BN2N□4-U		
Part No. (TIIS of	Part No. (TIIS certified)		EC2B-1102BF2N□1	EC2B-1102BF2N□2	EC2B-1102BF2N□3	EC2B-1102BF2N□4		
TIIS Type Test	Type Test C termi- nal style TC19254		TC19254	TC19254	TC19254			
Approval No. (F terr		TC19255	TC19255	TC19255	TC19255		

Pilot Lights

Pilot Lights							
Shape/Symbol Mounted Control Units							
		100/110V AC Illumination color: red	200/220V AC Illumination color: red	24V AC/DC Illumination color: red	100/110V AC Illumination color: green	200/220V AC Illumination color: green	24V AC/DC Illumination color: green
Part No. (IECEx/ATEX/Ex-C certified)	ccc	EC2B- 1101BM3N□1-GL	EC2B- 1101BM3N□2-GL	EC2B- 1101BM3N□3-GL	EC2B- 1101BM3N□4-GL	EC2B- 1101BM3N□5-GL	EC2B- 1101BM3N□6-GL
Part No. (UL/c-UL, IECEX/certified)	ATEX	EC2B- 1101BN2N□1-U	EC2B- 1101BN2N□2-U	EC2B- 1101BN2N□3-U	EC2B- 1101BN2N□4-U	EC2B- 1101BN2N□5-U	EC2B- 1101BN2N□6-U
Part No. (TIIS certified)		EC2B- 1101BF2N□1	EC2B- 1101BF2N□2	EC2B- 1101BF2N□3	EC2B- 1101BF2N□4	EC2B- 1101BF2N□5	EC2B- 1101BF2N□6
TIIS Type Test	C termi- nal style	TC19254	TC19254	TC19254	TC19254	TC19254	TC19254
Approval No. (*)	F termi- nal style	TC19255	TC19255	TC19255	TC19255	TC19255	TC19255

Emergency Stop Switches

Shape/Sym	lodr		Mounted Control Units
	1 0	1	Emergency stop switch 2NC contact Nameplate EMERGENCY STOP Button color (red)
Part No. (IECEx/ATEX/Ex-CCC certified)			EC2B-1102BM3N□7-GL
Part No. (UL/c-UL, IECEX/ATEX certified)			EC2B-1102BN2N□7-U
Part No. (TIIS certified)			EC2B-1102BF2N□7
TIIS Type Test	C termi- nal style		TC19254
Approval No. (*)	F termi- nal style		TC19255

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- * C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

1 Control Unit × 1 Column (without wiring) (standard models)

Selector Switches

Shape/S	ymbol		Mounted Control Units		
OFF ON 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		1	Knob selector 2-position maintained 1NO-1NC contact Name plate OFF-ON		
Part No. (IECEx/ATEX/Ex-	CCC certif	ied)	EC2B-1106BM3N□1-GL		
Part No. (UL/c-UL, IECE certified)	X/ATEX		EC2B-1106BN2N□1-U		
Part No. (TIIS certified)			EC2B-1106BF2N□1		
TIIS Type Test Approval No. (*)	C terminal style		TC19256		
	F termin style	al	TC19257		

Key Selector Switches

Shape/Sy	/mbol	Mounted Control Units	
0FF ON 7 \ 0 \ 2 \ 4		Key selector 2-position maintained OFF ON (removable at all positions) 1NO-1NC contact Nameplate OFF-ON	
Part No. (IECEx/ATEX/Ex-	CCC certified)	EC2B-1106BM3N□4-GL	
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-1106BN2N□4-U	
Part No. (TIIS certified)		EC2B-1106BF2N□4	
TIIS Type Test	C terminal style	TC19256	
Approval No. (*)	F terminal style	TC19257	

2 Control Units × 1 Column (without wiring) (standard models)

Two Flush Pushbuttons

Shape/Syr	nbol		Mounted Control Units
		1	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)
	2	2	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)
Part No. (IECEx/ATEX/Ex-C	CC ce	ertified)	EC2B-2102BM3N□1-GL
Part No. (UL/c-UL, IECEX/ATEX certified)		X	EC2B-2102BN2N□1-U
Part No. (TIIS cer	rtified	d)	EC2B-2102BF2N□1
TIIS Type Test	C terminal style		TC19254
Approval No. (*)	F terminal style		TC19255

Two Mushroom Pushbuttons

Character (Countries)					
Shape/Symbol			Mounted Control Units		
[3]	1 0	1	Mushroom momentary 1NO-1NC contact, Nameplate ON Button color (black)		
	2	2	Mushroom momentary 1NO-1NC contact, Nameplate OFF Button color (red)		
Part No. (IECEx/ATEX/Ex-CCC certified)		rtified)	EC2B-2102BM3N□4-GL		
Part No. (UL/c-UL, IECEX/ATEX certified)		<	EC2B-2102BN2N□4-U		
Part No. (TIIS certified))	EC2B-2102BF2N□4		
TIIS Type Test	C terminal style		TC19254		
Approval No. (*)	30 1001		TC19255		

Combination Pilot Lights/Pushbuttons

Shape/Symbol			Mounted Control Units				
W1		1			24V AC/DC Illumination color: red		
3	X2 ① 1 ② 2	2	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)		
Part No. (IECEx/ATEX/Ex-C	CCC certif	ied)	EC2B-2110BM3N□1-GL	EC2B-2110BM3N□2-GL	EC2B-2110BM3N□3-GL		
Part No. (UL/c-UL, IECEX/ATEX co	ertified)		EC2B-2110BN2N□1-U	EC2B-2110BN2N□2-U	EC2B-2110BN2N□3-U		
Part No. (TIIS certified)			EC2B-2110BF2N□1	EC2B-2110BF2N□2	EC2B-2110BF2N□3		
TIIS Type Test	C terminal style		TC19254	TC19254	TC19254		
Approval No. (*)	F terminal style TC19255		TC19255	TC19255	TC19255		

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- * C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

2 Control Units × 1 Column (without wiring) (standard models)

Combination Pilot Light/Selector Switch

Shape/Symbol			Mounted Control Units				
$X1 \times X2 \bigcirc 0$		1	100/110V AC Illumination color: red	200/220V AC Illumination color: red			
OFF ON	OFF ON 1 3 2 4		Knob, 2-position, 1NO-1NC contact Maintained, Name plate OFF-ON	Knob, 2-position, 1NO-1NC contact Maintained, Name plate OFF-ON			
Part No. (IECEx/ATEX/Ex-C	Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-2117BM3N□1-GL	EC2B-2117BM3N□2-GL			
Part No. (UL/c-UL, IECEX/A	Part No. (UL/c-UL, IECEX/ATEX certifie		EC2B-2117BN2N□1-U	EC2B-2117BN2N□2-U			
Part No. (TIIS certi	Part No. (TIIS certified)		EC2B-2117BF2N□1	EC2B-2117BF2N□2			
TIIS Type Test C termina		al	TC19258	TC19258			
Approval No. (*)	F termin style	al	TC19259	TC19259			

3 Control Units × 1 Column (without wiring) (standard models)

Combination 1 pilot light/2 pushbuttons

Shape/Syr	mbol		Mounted Control Units					
V1	<u>X1</u> _⊗ X2	1	100/110V AC Illumination color: red	200/220V AC Illumination color: red	24V AC/DC Illumination color: red			
	1 ①	2	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)			
F/	2 ②	3	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)			
Part No. (IECEx/ATEX/Ex-C	CC cert	tified)	EC2B-3110BM3N□1-GL	EC2B-3110BM3N□2-GL	EC2B-3110BM3N□3-GL			
Part No. (UL/c-U ATEX certified)	Part No. (UL/c-UL, IECEX/ ATEX certified)		EC2B-3110BN2N□1-U	EC2B-3110BN2N□2-U	EC2B-3110BN2N□3-U			
Part No. (TIIS cer	Part No. (TIIS certified)		EC2B-3110BF2N□1	EC2B-3110BF2N□2	EC2B-3110BF2N□3			
TIIS Type Test	C tern	minal	TC19260	TC19260	TC19260			
Approval No. (*)	F tern style	ninal	TC19261	TC19261	TC19261			

3 Pushbuttons

O USIDALIOIS							
Shape/Syr	nbol		Mounted Control Units				
3	1	1	Flush momentary				
3	1 2	2	1NO-1NC contact, Blank nameplate Button color (supplied with black,				
3	1 7 3 2	3	green, red, and white buttons)				
Part No. (IECEx/ATEX/Ex-CCC certified)			EC2B-3102BM3N□1-GL				
Part No.(UL/c-UL, IECEX/ ATEX certified)		EX/	EC2B-3102BN2N□1-U				
Part No. (TIIS cer	rtified)		EC2B-3102BF2N□1				
TIIS Type Test	C terminal style		TC19260				
Approval No. (*)	F terminal style		TC19261				

1 Meter/2 Pushbuttons

Shape/Symbol		Mounted Control Units
[j	1	Specify input, capacity, and scale
3 1 2 2	2	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)
3 1 3 4 2 3	3	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)
Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-3152BM3N□1△-GL
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-3152BN2N□1△-U

- Specify the meter's capacity and scale in place of △ in the part no. See page 17 for details. Contact IDEC for custom assembled control boxes.
- TIIS certified control box equipped with a meter is available with combination of other than 1 unit/1 column, 2 units/1 column, and 3 units/1 column.
- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- * C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

4 Control Units × 1 Column (without wiring) (standard models)

2 pilot lights/2 pushbuttons

Shape/Symbol			Mounted Control Units				
• • ;	1	100/110V AC, Illumination color: red	200/220V AC, Illumination color: red	24V AC/DC, Illumination color: red			
<u>X1</u> <u>X2</u> ⊕	2	100/110V AC, Illumination color: green	200/220V AC, Illumination color: green	24V AC/DC, Illumination color: green			
$\begin{array}{c c} X1 \otimes X2 & @ \\ \hline & 3 1 & \\ \hline & 4 2 & \\ \hline \end{array}$	3	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)			
3 1 4 2 4	4	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)			
Part No. (IECEx/ATEX/Ex-CCC certi	fied)	EC2B-4110BM4N□1-GL	EC2B-4110BM4N□2-GL	EC2B-4110BM4N□3-GL			
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-4110BN3N□1-U	EC2B-4110BN3N□2-U	EC2B-4110BN3N□3-U			
Part No. (TIIS certified)		EC2B-4110BF3N□1	EC2B-4110BF3N□2	EC2B-4110BF3N□3			
TIIS Type Test C/F terr Approval No. (*)		TC19262	TC19262	TC19262			

1 pilot light/2 pushbuttons/1 selector switch

Shape/Symbol			Mounted Control Units		
		100/110V AC, Illumination color: red 200/220V AC, Illumination color: red		24V AC/DC, Illumination color: red	
$\begin{array}{c c} X1 \times X2 \\ \hline 3 & 3 & 1 \\ \hline 4 & 2 & 3 \end{array}$		1NO-1NC contact, Nameplate ON Button color (supplied with black, Button color (supplied with black,		Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	
3 1 3 1 4 2 HAND AUTO 1	3	Flush momentary INO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons) Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)		Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	
1 3	4	Knob, 2-position, maintained HAND AUTO 1NO-1NC contact, Nameplate HAND-AUTO	Knob, 2-position, maintained 1NO-1NC contact, Nameplate HAND-AUTO	Knob, 2-position, maintained HAND AUTO 1NO-1NC contact, Nameplate HAND-AUTO	
Part No. (IECEx/ATEX/Ex-CCC certifi	ed)	EC2B-4113BM4N□1-GL	EC2B-4113B□4N□2-GL	EC2B-4113B□4N□3-GL	
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-4113BN3N□1-U	EC2B-4113BN3N□2-U	EC2B-4113BN3N□3-U	
Part No. (TIIS certified)		EC2B-4113BF3N□1	EC2B-4113BF3N□2	EC2B-4113BF3N□3	
TIIS Type Test C/F ter Approval No. (*)	minal	TC19262	TC19262 TC19262		

5 Control Units × 1 Column (without wiring) (standard models)

2 pilot lights/2 pushbuttons/1 selector switch

Shape/Symbol		Mounted Control Units			
F——	1	100/110V AC, Illumination color: red	200/220V AC, Illumination color: red	24V AC/DC, Illumination color: red	
$\begin{array}{c c} X1 \times X2 & 0 \\ \hline X1 \times X2 & 0 \\ \hline X1 \times X2 & 0 \\ \hline & 3 \mid 1 \\ \hline & 4 \mid 2 \\ \end{array}$	2	100/110V AC, Illumination color: green	100/110V AC, Illumination color: green	24V AC/DC, Illumination color: green	
	3	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	
3 1 3 1 4 2 4 2 0 OFF ON 1 1 0	4	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	
5 1 3 S	(3)	Knob, 2-position, Maintained, 1NO-1NC contact, Name plate HAND-AUTO	Knob, 2-position, Maintained, 1NO-1NC contact Name plate HAND-AUTO	Knob, 2-position, Maintained, 1NO-1NC contact Name plate HAND-AUTO	
Part No. (IECEx/ATEX/Ex-CCC certi	fied)	EC2B-5113BM4N□1-GL	EC2B-5113BM4N□2-GL	EC2B-5113BM4N□3-GL	
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-5113BN3N□1-U	EC2B-5113BN3N□2-U	EC2B-5113BN3N□3-U	
Part No. (TIIS certified)		EC2B-5113BF3N□1	EC2B-5113BF3N□2	EC2B-5113BF3N□3	
TIIS Type Test C/F terminal style		TC19262	TC19262	TC19262	

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
 Contact IDEC for custom assembled control boxes.
- * C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

Cable Lead-in Fittings

Wall Mount Reducers

Reducers installed at the bottom of the control box are as follows:

1 column: 1 reducer2 columns: 2 reducers3 columns: 3 reducers4 columns: 4 reducersMaterial: brass (nickel-plated)



The following optional reducers can also be installed.

				Ap	prova	al
Control Box Style	Part No.	Thread Size	Sym- bol	IECEX ATEX Ex-CCC	UL c-UL	TIIS
	EC9E-H31 *1	G1/2 (16)	F1	0	_	0
	EC9E-H32 *1	G3/4 (22)	F2	0	_	•
1 column	EC9E-H33 *1	G1 (28)	F3	0	_	0
(1 to 3 control	EC9E-H3M16 *2	M16	M1	0	0	0
units)	EC9E-H3M20 *2	M20	M2	0	0	0
2, 3 col-	EC9E-H3M25 *2	M25	М3	•	0	0
umns	EC9E-H3M32 *2	M32	M4	0	0	0
(2, 3 con- trol units)	EC9E-H3NPT1 *2	NPT 1/2	N1	0	0	0
u or armo,	EC9E-H3NPT2 *2	NPT 3/4	N2	0	•	0
	EC9E-H3NPT3 *2	NPT 1	N3	0	0	0
	EC9E-H42 *1	G3/4 (22)	F2	0	_	0
	EC9E-H43 *1	G1 (28)	F3	0	_	•
1, 2, 3 columns	EC9E-H44 *1	G1 1/4 (36)	F4	0	_	0
(4, 5 con- trol units)	EC9E-H4M25 *2	M25	М3	0	0	0
3, 4 columns (6 control units)	EC9E-H4M32 *2	M32	M4	•	0	0
	EC9E-H4M40 *2	M40	M5	0	0	0
	EC9E-H4NPT2 *2	NPT 3/4	N2	0	0	0
uill(S)	EC9E-H4NPT3 *2	NPT 1	N3	0	•	0
	EC9E-H4NPT4 *2	NPT 1 1/4	N4	0	0	0

: Standard reducer

O: Except for standard reducer

Specify the reducer certification in place of ______.

*1 E: IECEx, ATEX, Ex-CCC Blank: TIIS certified

*2 E-UL: IECx/ATEX, UL/c-UL certified Blank: TIIS certified

 The value in () is the nominal designation of the applicable metal conduit (JIS C 8305)

Pole Mount (for TIIS certified model only)

Packing Type Cable Lead-in Fitting

Only one cable can be lead in.



Three different packings are available for 1-, 2-, and 3-column.

Material: Brass (nickel-plated)

Box Style	Part No.	Packing	Cable Diameter D (mm)	Symbol
		R12	$\emptyset 8 \le D \le \emptyset 12$	
1 column	EC9E-S10	R16	ø12 < D ≤ ø16	
		R20	ø16 < D ≤ ø20	SF
0.0		R18	ø14 ≤ D ≤ ø18	55
2, 3 column	EC9E-S20	R22	ø18 < D ≤ ø22	
		R26	ø22 < D < ø26	

Flameproof Packing Type Cable Lead-in Fittings (for TIIS certified model only)


Used to lead in rubber and plastic cables.

Material: Brass (nickel-plated)



Flameproof packing	Applicable cable diameter		Dimensions (mm)			
type cable lead-in fitting	D (mm)	Symbol	А	В	L	
HPN21 R8	$\emptyset 6 \le D \le \emptyset 8$	H1		04/0	07.	
HPN21 R10	ø8 < D ≤ ø10	H2	36	G1/2 (16)	67 to 70.5	
HPN21 R12	$\emptyset 10 < D \le \emptyset 12$	НЗ		(10)	70.5	
HPN22 R14	$\emptyset 12 < D \le \emptyset 14$	H4	40	G3/4	67 to	
HPN22 R16	$\emptyset 14 < D \le \emptyset 16$	H5	40	(22)	70.5	
HPN33 R18	$\emptyset 16 < D \le \emptyset 18$	H6	50	C1 (00)	77.5 to	
HPN33 R20	$\emptyset 18 < D \le \emptyset 20$	H7	50	G1 (28)	81	
HPN44 R23	$\emptyset 20 < D \le \emptyset 23$	HA	E0	G1 1/4	80.5 to	
HPN44 R26	$\emptyset 23 < D \le \emptyset 26$	HB	58	(36)	84	

- HPN44 cannot be used for 1, 2, or 3 control units/1 column.
- The dimension of B in () is the nominal designation of the applicable metal conduit. (JIS C 8305)
- When ordering TIIS certified model, specify the part no. of flameproof packing type cable lead-in fitting.



* For IECEx/ATEX/Ex-CCC, UL/c-UL certified control boxes, use cable lead-in fittings that are commercially available.

Terminal Blocks

A terminal block is not supplied with the standard control boxes (without wiring). When wiring inside the control box is required, specify the wiring circuit.

The terminal block type used on the control boxes with wiring depends on the terminal style of the control unit.


C terminal style (exposed screw terminal)

[Applicable terminal block]

Screw terminal: ET2A-8PE (material: polyamide)

Certification numbers:

IECEx TUR 15.0043U TÜV 15 ATEX 7799U



All dimensions in mm.


F terminal style (finger-safe screw terminal)

[Applicable terminal block]

IP20 clamp terminal: 264-238 (WAGO) (material: polyamide) Certification numbers:


IECEx PTB 04.0003U


PTB 98 ATEX 3129U




All dimensions in mm.

The number of terminal blocks, poles, and the installation direction that can be installed on the control box are as follows:









Dimensions

1, 2 Control Units × 1 Column


* Pole mount: TIIS certified model only



3 Control Units × 1 Column




4, 5 Control Units × 1 Column




2, 3, 4, 5 control units × 2 Columns

* Pole mount: TIIS certified model only




2, 3, 4, 5 control units × 3 Columns



6 control units × 3 columns

Dimensions (mm) Control Unit Mounting Holes 140 4-o10 (mounting hole) 4-o10 (mounting tab) Reducer (m4 grounding terminal) M5 lid mounting screw

6 control units × 4 columns



Control Units

Applicable Standards

Applicable	Stariuarus		
Control Units	Applicable Standards	Mark	Certification No.
	GB 12476.1 GB 12476.5 GB 3836.1 GB 3836.2 GB 3836.3	(2021012304363041 2021012304363046 2021012309370228 2021012313363039
	EN60947-5-1	(€	EU Low Voltage Directive
Pushbuttons Selector	UL60079-0 UL60079-1 UL60079-7		
Switches Key Selector Switches Pilot Lights Meters (EU2B-YM)	CAN/CSA C22.2 No. 60079-0 CAN/CSA C22.2 No. 60079-1 CAN/CSA C22.2 No. 60079-7	CUL US	E347230
	EN60079-0 EN60079-1 EN60079-7 EN60079-31	Œx>	PTB 08 ATEX 1053U PTB 08 ATEX 1003U
	IEC60079-0 IEC60079-1 IEC60079-7 IEC60079-31	IECEX	IECEX PTB 15.0006U IECEX PTB 15.0007U
Emergency Stop Switches	EN60947-5-5		

Pilot Light Specifications

Filot Light Specifications								
Rated Insulation Voltage (Ui)	500V							
Rated Operating	6, 12, 24V AC/DC							
Voltage (Ue)	100/110, 115, 120, 200/220 230, 240, 380, 400/440, 480V AC							
Impulse Withstand Voltage (Uimp)	4kV							
Insulation Resistance	100 MΩ minumum (500V DC)							
Frequency	50/60Hz							
Power Consumption	0.3W (24V AC/DC)							
(approx.)	1.5W (100/110V AC)							
Life (reference value)	Approx. 40,000 hours							

 Because the built-in LED lamp is a high-luminance type, the lamp may light dimly due to induction even when the power is off.

Switch Specifications

Contact Resistance	50mΩ maximum	50mΩ maximum (initial value)					
Impulse Withstand Voltage (Uimp)	6kV						
Insulation Resistance	100MΩ minimum	(500V DC megger)					
Short-circuit Protection	250V/10A fuse (T	ype aM IEC60269-1/IEC60269-2)					
Conditional Short- circuit Current	1,000A						
	Pushbutton	1,000,000 operations minimum					
	Selector Switch	500,000 operations minimum					
Mechanical Life	Key Selector Switch	500,000 operations minimum					
	Emergency Stop Switch	50,000 operations minimum					
	Pushbutton	250,000 operations minimum (switching frequency 1800 operations/h)					
Electrical Life	Selector Switch	250,000 operations minimum (switching frequency 900 operations/h)					
Electrical Life	Key Selector Switch	250,000 operations minimum (switching frequency 900 operations/h)					
	Emergency Stop Switch	50,000 operations minimum (switching frequency 900 operations/h)					
Minimum Force Required for Direct Action	Emergency Stop Switch	60N					
Minimum Operator Stroke Required for Direct Opening Action	Emergency Stop Switch	7.0mm					
Maximum Operator Stroke	Emergency Stop Switch	9.0mm					

• Contact bounce

Contacts will bounce during operation of pushbuttons and selector switches (reference value: 20 ms). Be sure to take contact bounce time into consideration when designing a control circuit.

 Replacing the control units, nameplates, padlock covers, and LED lamps by users affect the explosion-proof performance which is not guaranteed. Contact IDEC when replacement is necessary.

Contact Ratings

IECEx/ATEX/Ex-CCC, TIIS certified

Rated Insula	ation Volta	ge (Ui)	600V				
Rated Therr	mal Currer	nt (Ith)	10A (*)				
Rated Oper	ating Volta	24V	120V	240V	500V		
AC	AC	Resistive Load (AC12)	10A (*)	10A (*)	6A	2.8A	
Rated Operating	50/60Hz	Inductive Load (AC15)	10A (*)	6A	ЗА	1.4A	
Current (le)	DC	Resistive Load (DC12)	8A	2.2A	1.1A	_	
		Inductive Load (DC13)	4A	1.1A	0.55A	_	

* Up to 2 contacts (per control unit): 10A3 contacts (per control unit): 9A

Minimum applicable load: 3V AC/DC, 5 mA

Applicable operating locations may vary according to operating conditions and load types.

• TÜV ratings (emergency stop switches) AC-15 250V/3A

DC-13 125V/1.1A

• UL/c-UL ratings: 600V/10A

Buzzer Specifications (EC9F-Z)

Rated Insulation Voltage (Ui)	250V
Rated Operation Voltage	110V AC, 220V AC (50/60Hz)
Time Rating	10 minutes
Sound Pressure (at 1m)	80dB minimum
Power	8VA maximum

 If the sound continues longer than the time rating, the internal parts may overheat and explosion-proof characteristics may be impaired.

Variable Resistor Specifications (EC9E-R)

Rated Power	1W or 2.5W (at 40°C)
Resistance Range	1, 2, 3, 5, 10kΩ Tolerance: ±10%, Characteristics: Linear
Insulation Resistance	100MΩ minimum (500V DC meggar)

- To maintain stable performance for a long period of time, use only up to about 50% of the rated power capacity.
- The variable resistor is available on control boxes with wiring.


Meter Specifications (EU2B-YM/EC9F-M)

		(LOZD TIVI) LOOF IVI)			
Accuracy	Class	2.5 (JIS)			
Insulation	Resistance	100 MΩ minimum (500V DC megger)			
	Rated Insulation Voltage (Ui)	300V			
	Operation	Moving core			
AC	Impulse Withstand Voltage (Uimp)	4kV			
Ammeter	Power Consumption	1VA			
	Measurement	5A, 10A, 30A, 50A, etc			
	Input (CT Ratio)	1A, 5A			
	Extended Memory	3 times, etc			
	Rated Insulation Voltage (Ui)	150V			
	Operation	Moving coil			
DC	Impulse Withstand Voltage (Uimp)	2.5kV			
Ammeter	Input	0 to 10V DC, 4 to 20mA DC, etc			
	Power Consumption (DC ammeter)	0.01W			
	Power Consumption (DC voltmeter)	1mA			

- Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum. Install the CT in a non-hazardous location.
- AC and DC ammeters other than listed above are also available upon request, such as extended scale or red pointer.

Pointer Zero Adjustment and Red Pointer Adjustment

- Using a flat screwdriver, turn the zero adjustment pointer screw and the red pointer screw (see below).
- Zero adjustment is possible only on AC ammeters. On other meters such as DC voltmeters, DC ammeters, and tachometer, zero adjustment is not possible.



Control Units

Pilot Lights

			Part	Illumination Calar	Majaht	
Shape	Symbol	Contact Rating	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Illumination Color Code *	Weight (approx.)
15/		100/110V AC 50/60Hz	EU2B-YL116CD∗□	EU2B-YL116FD∗□	R: red G: green	150g
	PL)	200/220V AC 50/60Hz	EU2B-YL126CD∗□	EU2B-YL126FD∗□	A: amber Y: yellow W: white	150g
		24V AC/DC	EU2B-YL122CD∗□	EU2B-YL122FD∗□	S: blue PW: pure white	108g
Dimensions (mm)	C Termina	al Style ckness 1 to 4.5	F Terminal Style Panel Thickness 1 to 4.5	, 32.5	. X1	
		13.3	13.3		X2	
		67.7 20.3	67.7	61.4	(All dimen	sions in mm.)

- Other voltages are available: 6V AC/DC, 12V AC/DC, 115V AC, 120V AC, 230V AC, 240V AC, 380V AC, 400/440V AC, 480V AC, 100/110/120V AC/DC, 230/240V AC/DC. For details, see page 18.
 Because LED illuminated pilot lights have small input currents, they may light due to induction even when the power is off.
 Specify an illumination color code in place of * in the Part No.
 Specify the reducer certification code in place of □. -T: TIIS certified, Blank: IECEx/ATEX/Ex-CCC, UL/c-UL certified

Pushbuttons

				Contact	Part	t No.	Dutter Calan	\\/a:a.la±
Shape Symbol Operation		Operation	Operator	Arrange- ment	C terminal style: exposed screw terminal	F terminal style: finger-safe screw termina	Button Color Code	Weight (approx.)
				1NO	EU2B-YB110C∗□	EU2B-YB110F∗□	Blank: supplied with four buttons	68g
			Flush	1NC	EU2B-YB101C∗□	EU2B-YB101F∗□	(B, G, R, W)	oog
Ha-				1NO-1NC	EU2B-YB111C∗□	EU2B-YB111F∗□	Y: yellow S: blue	92g
	(PB)	Momen-		1NO	EU2B-YB210C∗□	EU2B-YB210F∗□		70 =
		tary	tary Extended		EU2B-YB201C∗□	EU2B-YB201F∗□	B: black G: green	70g
				1NO-1NC	EU2B-YB211C∗□	EU2B-YB211F∗□	R: red	94g
			Mush- room	1NO	EU2B-YB310C∗□	EU2B-YB310F∗□	W: white	760
				1NC	EU2B-YB301C∗□	EU2B-YB301F∗□	Y: yellow S: blue	76g
				1NO-1NC	EU2B-YB311C∗□	EU2B-YB311F∗□		101g
Dimensions (mm) Flush (C Terminal Styl	le)	Flush (l	Terminal Style	e)		Extended Mushroom	NO N	10
Panel Thickness 1 to	4.5	Panel 1	hickness 1 to 4	4.5	32.2	1	4 2	2
		84 -0.		<u>1</u> 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	88	0536	3	<i>†</i>
67.7	13.3	-	67.7	13.3	47.4	19.3	(All dimens	ons in mm.)

- Other contact arragements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) are also available. See page 18.
- Specify a button color code in place of * in the Part No.
- Specify the reducer certification code in place of \square . Blank: TIIS certified, -D: IECEx/ATEX/Ex-CCC, UL/c-UL certified

Emergency Stop Switches

			0	Part	D	\\/a:lat		
Shape	Symbol	Operation	Operator	Contact Arrangement	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Button color	Weight (approx.)
U				2NC	EU2B-YBV302CR	EU2B-YBV302FR		120g
Push-to-lock or Turn-to-		ø40 Mushroom	1NO-2NC EU2B-YBV312CR		EU2B-YBV312FR	Red	144g	
\Rightarrow				3NC	EU2B-YBV303CR	EU2B-YBV303FR		1449
Dimensions (mm)	C Termin	al Style Pa	nel Thickness 1 to	4.5 F Terminal S	Style Panel Thickness 1	to 4.5	NO N	
						488	4 2 	
		67.7	35	- (67.7 35	47.4	(All dimensi	ons in mm.)

- Other contact arrangements (1NC, 1NO-1NC) are also available. See page 18 for details.
 Emergency stop switches are only available with a red button.

Selector Switches

NC contact: direct opening action (IEC 60947-5-1 Annex K)

		No. of	Contac	t Block		rato		Pa	Weight	
Shape Symb	Symbol	Posi- tions	Mounting Position	Contact	1	2	Operation	C terminal style:	F terminal style: finger-safe screw terminal	(approx.)
		2-posi-	1	NO		•	Maintained			
		tion	2	_			L R	EU2B-YS211C	EU2B-YS211F	98g
		90°	3	NC	•					
	ES				1	2				
		3-position 45°	1	NO			Maintained			
			2	_			L C R	EU2B-YS320C	EU2B-YS320F	98g
			3	NO		•				
Dimensions (mm)	C Termina	l Style		F Ten	minal S	tyle			Operator Position	
	Panel Thic	kness 1 to 4.5		Panel Thickness 1 to 4.5					1 2	NO NC
Contact @ Block Position (a) (a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c								3 1		
	-	····	+ -7.0 +	-			+ 27.0	+ + + + + + + + + + + + + + + + + + + +	(All dimen	sions in mm.)

- Other contact arrangements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) and overlapping contacts are also available.
- Spring return from right, spring return from left, spring return two-way also available. See pages 19 to 20.

Key Selector Switches

NC contact: direct opening action (IEC 60947-5-1 Annex K)

		No. of	Contac	t Block		rator ition		Pa	rt No.	Weight
Shape	Symbol	Posi- tions	Mounting Position	Contact	1	2	Operation	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	(approx.)
		2-posi-	①	NO		•	Maintained			
		tion	2	_			L R	EU2B-YSK211CA	EU2B-YSK211FA	120g
		90°	3	NC	•					
	ES	3-posi- tion			1 (2				
			①	NO	•		Maintained			
			2	_			L C R	EU2B-YSK320CA	EU2B-YSK320FA	120g
		45°	3	NC		•				
Dimensions (mm)	C Terminal	Style		F Te	rminal S	Style		-GL, -UL	Operator Posi	tion
	Panel Thic	kness 1 to 4.5	si ie	Pa	anel Th	icknes	s 1 to 4.5	_	32.2 C	
	CHI CHI	13.3 38.3	040		67.	13.3	38.3	(All dimen	© Contac © Block Positic © sions in mm.)	

- Other contact arrangements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) and overlapping contacts are also available.
- Spring return from right, spring return from left, spring return two-way also available.
- On the spring-returned, the key can released only from the maintained position. On the maintained, the key can be released from every position.
- Key retained position can be selected. See pages 19 to 20.
- Each key selector switch is supplied with two identical keys. Three different keys are also available.

Buzzer (for TIIS certified model only) (Cannot be installed on 1 to 3 units × 1 column boxes.)

	Shape	Symbol	Rated Power (50/60Hz)	Part No.	Sound Volume (at 1m)	Sound Duration	Power Con- sumption	Weight (approx.)	Dimensions
			110V AC	EC9F-Z11N	00 d D		8VA maximum		Terminal Screw M4
		BZ)	220V AC	EC9F-Z12N	80dB minimum	10 minutes *		0.4kg	No finger-safe screw terminal model available.

* Do not exceed the sound duration time, otherwise internal heating will result.

Variable Resistors (for TIIS certified model only) (Cannot be installed on 1 to 5 units × 1 column boxes.)

Shape	Symbol	Resistance Range	Part No.	Rated Power	Insulation Resistance	Weight (approx.)	Dimensions (mm)
	(R)	1, 2, 3, 5, 10kΩ Tolerance±10% Characteristics: linear	EC9E-R	1W, 2.5W (at 40oC)	100MΩ minimum (500V DC)	0.45kg	60 33 55 a10 cable

- The variable resistor is available on control boxes with wiring.
- Specify resistance value and rated power when ordering.

Meters (IECEx/ATEX/Ex-CCC, UL/c-UL Certified)

Shape	Sym- bol	Input	Part No.	Specif	ications	Capacity/ Scale Code	Weight (approx.)	Dimensions (mm)
			EU2B-YM53A5△	Capacity: 5A	Expansion scale ×3	5A (3)		
			EU2B-YM53A10△	Capacity: 10/5A	Expansion scale ×3	10/5A (3)		
			EU2B-YM13A10△	Capacity: 10/1A	Expansion scale ×3	10/1A (3)		
			EU2B-YM53A15△	Capacity: 15/5A	Expansion scale ×3	15/5A (3)		
			EU2B-YM13A15△	Capacity: 15/1A	Expansion scale ×3	15/1A (3)		Screw Terminal
		AC input	EU2B-YM13A20△	Capacity: 20/1A	Expansion scale ×3	20/1A (3)		Terminal Screw M3.5
		meter	EU2B-YM53A30△	Capacity: 30/5A	Expansion scale ×3	30/5A (3)	1	
		(ammeter)	EU2B-YM13A30△	Capacity: 30/1A	Expansion scale ×3	30/1A (3)		
			EU2B-YM53A50△	Capacity: 50/5A	Expansion scale ×3	50/5A (3)		60.1 33.5
A CONTRACTOR OF THE PARTY OF TH	M		EU2B-YM53A60△	Capacity: 60/5A	Expansion scale ×3	60/1A (3)	0.01	
A CONTRACTOR OF THE PARTY OF TH			EU2B-YM53A75△	Capacity: 75/5A	Expansion scale ×3	75/5A (3)	0.3kg	
			EU2B-YM53A100△	Capacity: 100/5A	Expansion scale ×3	100/5A (3)		Finger-safe Screw Terminal
			EU2B-YM53A150△	Capacity: 150/5A	Expansion scale ×3	150/5A (3)		Terminal Screw M3.5
			EU2B-YM010VD△-PER	0-10V DC input	Scale: 0 to 100%	010VD-PER		
			EU2B-YM010VD△-60HZ	0-10V DC input	Scale: 0 to 60Hz	010VD-60HZ		
			EU2B-YM001MD△-PER	0-1mA DC input	Scale: 0 to 100%	001MD-PER		62.1 33.5
		DC input meter	EU2B-YM001MD△-60HZ	0-1mA DC input	Scale: 0 to 60Hz	001MD-60HZ		
		meter	EU2B-YM001MD△-80HZ	0-1mA DC input	Scale: 0 to 80Hz	001MD-80HZ		
			EU2B-YM420MD△-PER	4-20mA DC input	Scale: 0 to 100%	420MD-PER		
			EU2B-YM420MD△-60HZ	4-20mA DC input	Scale: 0 to 60Hz	420MD-60HZ		

- Specify a terminal style in place of △ in the Part No. C: exposed screw terminal), F: finger-safe screw terminal
 Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum. Install the CT in a non-hazardous location.
 AC and DC ammeters other than listed above are also available upon request.

Meters (TIIS certified model only) (Cannot be installed on 1 to 3 units × 1 column boxes.)

Shape	Symbol	Input	Part No.	Specif	ications	Weight (approx.)	Dimensions (mm)							
			EC9F-M53A5N	Capacity: 5A	Expansion scale ×3									
			EC9F-M53A10N	Capacity: 10/5A	Expansion scale ×3									
			EC9F-M13A10N	Capacity: 10/1A	Expansion scale ×3									
			EC9F-M53A15N	Capacity: 15/5A	Expansion scale ×3									
			EC9F-M13A15N	Capacity: 15/1A	Expansion scale ×3									
		AC input	EC9F-M13A20N	Capacity: 20/1A	Expansion scale ×3									
		meter	EC9F-M53A30N	Capacity: 30/5A	Expansion scale ×3		Terminal							
		ammeter)	EC9F-M13A30N	Capacity: 30/1A	Expansion scale ×3		Screw M4							
			EC9F-M53A50N	Capacity: 50/5A	Expansion scale ×3									
A	M		EC9F-M53A60N	Capacity: 60/5A	Expansion scale ×3	0.3kg								
-											EC9F-M53A75N	Capacity: 75/5A	Expansion scale ×3	U.SKY
			EC9F-M53A100N	Capacity: 100/5A	Expansion scale ×3		58.0 33.5							
			EC9F-M53A150N	Capacity: 150/5A	Expansion scale ×3		No finger-safe screw terminal							
			EC9F-M010VD-PER	0-10V DC input	Scale: 0 to 100%		model available.							
			EC9F-M010VD-60HZ	0-10V DC input	Scale: 0 to 60Hz									
			EC9F-M01MD-PER	0-1mA DC input	Scale: 0 to 100%									
		DC input meter	EC9F-M01MD-60HZ	0-1mA DC input	Scale: 0 to 60Hz									
		meter	EC9F-M01MD-80HZ	0-1mA DC input	Scale: 0 to 80Hz									
			EC9F-M420MD-PER	4-20mA DC input	Scale: 0 to 100%									
			EC9F-M420MD-60HZ	4-20mA DC input	Scale: 0 to 60Hz									

- Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum.
 Install the CT in a non-hazardous location.
- AC and DC ammeters other than listed above are also available upon request.

Available Control Units

Pilot Lights

la a d	Dated Valtage	Pari	No.	Illumination Color				
Input	Rated Voltage	Exposed Screw Terminal	Finger-safe Screw Terminal	Code *				
	100/110V AC	EU2B-YL116CD∗□	EU2B-YL116FD∗□					
	115V AC	EU2B-YL1116CD∗□	EU2B-YL1116FD∗□					
	120V AC	EU2B-YL1126CD∗□	EU2B-YL1126FD∗□					
	200/220V AC	EU2B-YL126CD∗□	EU2B-YL126FD∗□					
AC	230V AC	EU2B-YL1236CD∗□	EU2B-YL1236FD∗□	R: red G: green				
	240V AC	EU2B-YL1246CD∗□	EU2B-YL1246FD∗□	A: amber				
	380V AC	EU2B-YL1386CD∗□	EU2B-YL1386FD∗□	Y: yellow W: white				
	400/440V AC	EU2B-YL146CD∗□	EU2B-YL146FD∗□					
	480V AC	EU2B-YL1486CD∗□	EU2B-YL1486FD∗□	S: blue PW: pure white				
	6V AC/DC	EU2B-YL166CD∗□	EU2B-YL166FD∗□	F vv. pare write				
AC/DC	12V AC/DC	EU2B-YL111CD∗□	EU2B-YL111FD∗□					
AC/DC	24V AC/DC	EU2B-YL122CD∗□	EU2B-YL122FD∗□					
	100/110/120V AC/DC (Note 1)	EU2B-YL1110CD∗□	EU2B-YL1110FD∗□					

Pushbuttons

Operator	Operation	Button Color Code *									
Operator	Operation	Arrangement	Exposed Screw Terminal	Finger-safe Screw Terminal	Button Color Code *						
		1NO	EU2B-YB110C∗□	EU2B-YB110F∗□							
		1NC	EU2B-YB101C∗□	EU2B-YB101F∗□							
		1NO-1NC	EU2B-YB111C∗□	EU2B-YB111F∗□	Blank: supplied with B						
		2NO	EU2B-YB120C∗□	EU2B-YB120F∗□	(black), G (green), R (red)						
Flush	Momentary	2NC	EU2B-YB102C∗□	EU2B-YB102F∗□	and W (white) buttons.						
		2NO-1NC	EU2B-YB121C∗□	EU2B-YB121F∗□	Y: yellow						
		1NO-2NC	EU2B-YB112C∗□	EU2B-YB112F∗□	S: blue						
		3NO	EU2B-YB130C∗□	EU2B-YB130F∗□							
		3NC	EU2B-YB103C∗□	EU2B-YB103F∗□							
		1NO	EU2B-YB210C∗□	EU2B-YB210F∗□							
		1NC	EU2B-YB201C∗□	EU2B-YB201F∗□							
		1NO-1NC	EU2B-YB211C∗□	EU2B-YB211F∗□	B: black						
		2NO	EU2B-YB220C∗□	EU2B-YB220F∗□	G: green						
Extended	Momentary	Momentary	Momentary	Momentary	Momentary	Momentary	Momentary	2NC	EU2B-YB202C∗□	EU2B-YB202F∗□	R: red W: white
		2NO-1NC	EU2B-YB221C∗□	EU2B-YB221F∗□	Y: yellow						
		1NO-2NC	EU2B-YB212C∗□	EU2B-YB212F∗□	S: blue						
		3NO	EU2B-YB230C∗□	EU2B-YB230F∗□							
		3NC	EU2B-YB203C∗□	EU2B-YB203F∗□							
		1NO	EU2B-YB310C∗□	EU2B-YB310F∗□							
		1NC	EU2B-YB301C∗□	EU2B-YB301F∗□							
		1NO-1NC	EU2B-YB311C∗□	EU2B-YB311F∗□	B: black						
		2NO	EU2B-YB320C∗□	EU2B-YB320F∗□	G: green						
ø40 Mushroom	Momentary	2NC	EU2B-YB302C∗□	EU2B-YB302F∗□	R: red W: white						
IVIUSIIIOOIII		2NO-1NC	EU2B-YB321C∗□	EU2B-YB321F∗□	Y: yellow						
		1NO-2NC	EU2B-YB312C∗□	EU2B-YB312F∗□	S: blue						
		3NO	EU2B-YB330C∗□	EU2B-YB330F∗□							
		3NC	EU2B-YB303C∗□	EU2B-YB303F∗□							

Emergency Ston Switches

Emergency Stop Switches											
Oneveter	Contact Awangament	Part	No.								
Operator	Contact Arrangement	Exposed Screw Terminal	Finger-safe Screw Terminal								
	1NC	EU2B-YBV301CR	EU2B-YBV301FR								
40	1NO-1NC	EU2B-YBV311CR	EU2B-YBV311FR								
ø40 Mushroom	2NC	EU2B-YBV302CR	EU2B-YBV302FR								
Widdilloom	1NO-2NC	EU2B-YBV312CR	EU2B-YBV312FR								
	3NC	EU2B-YBV303CR	EU2B-YBV303FR								

[•] Emergency stop switches are only available with a red button.

Specify a color code in place of ∗ in the Part No.
 Specify the reducer certification code in place of □. -T: TIIS certified, Blank: IECEx/ATEX/Ex-CCC, UL/c-UL certified Note 1: For IECEx/ATEX/Ex-CCC, UL/c-UL

<sup>Specify a color code in place of * in the Part No.
Specify explosion-proof certification code in place of □ in the Part No. -D: IECEx/ATEX/Ex-CCC, UL/u-CL, Blank: TIIS,</sup>

Selector Switches (2-position)

SL	0	District		rator		F	Part No.		
ļ.	Contact	ontact Block Position		Selecto	r Switch	Key Selec	tor Switch		
of Positions	Mount- ing	Con-	L	R	Maintained (90°)	Spring return from right (60°)	Maintained (90°)	Spring return from right (60°)	\triangle : Terminal
S S	Position tact								
	①	NO		•					
	2				EU2B-YS210△	EU2B-YS2110△	EU2B-YSK210△♦	EU2B-YSK2110△B	
	3								
	0								
	2	NO	•		EU2B-YS201△	EU2B-YS2101△	EU2B-YSK201△♦	EU2B-YSK2101△B	
	3	NC NO	•	•					
	① ②	NO		_	EU2B-YS220△	EU2B-YS2120△	EU2B-YSK220△◇	EU2B-YSK2120△B	
	3	NO		•	EU2D-1322U	EU2D-13212U	EU2D-13N22UAV	EUZD-TSKZIZUAD	
nc	0	NC	•						
l∺	2		_		EU2B-YS202△	EU2B-YS2102△	EU2B-YSK202△◇	EU2B-YSK2102△B	
l g	3	NC	•		LOZD TOZOZ	LOZD TOZTOZZ	LOLD TOTALOL	LOZD TORZIOZZD	
2-position	①	NO		•					
	2				EU2B-YS211△	EU2B-YS2111△	EU2B-YSK211△♦	EU2B-YSK2111△B	C: Exposed screw
)9/	3	NC	•						terminal
2-position/60°	1	NO		•					F: Finger-safe
siti	2	NO		•	EU2B-YS230△	EU2B-YS2130△	EU2B-YSK230△♦	EU2B-YSK2130△B	screw terminal
bod	3	NO		•					
	0	NC NC	•		FLIOR VOCCO	ELIOD VOOLOG	ELIOD VOICOGO A A	FUOD VOICOLOS A D	
.06	3	NC			EU2B-YS203△	EU2B-YS2103△	EU2B-YSK203△♦	EU2B-YSK2103△B	
0)	0	NO	_	•					
	②	NO			EU2B-YS221△	EU2B-YS2121△	EU2B-YSK221△◇	EU2B-YSK2121△B	
	3	NC	•		LOZD-10ZZ1Z	LOZD-10Z1Z1Z		LOZD-TORZIZIZD	
	0	NO		•					
	2	NC	•		EU2B-YS212△	EU2B-YS2112△	EU2B-YSK212△♦	EU2B-YSK2112△B	
	3	NC	•				v		
	1								
	2				EU2B-YS2R11△	_	EU2B-YSK2R11△♦	_	
	3	NC							

- $\bullet \ \text{Specify a terminal style in place of} \ \triangle \ \text{in the Part No. C: exposed screw terminal, F: finger-safe screw terminal}$
- Specify a key removable position code in place of ♦ in the Part No. See below for details.

Selector Switches (2-position/inverse cam)

Su			One	rotor	Pa	art No.			
of Positions	Contact	Block	Ope Pos		Selector Switch	Key Selector Switch			
	Mount- ing	Con-	L R		Maintained (90°)	Maintained (90°)	△: Terminal		
No.	Position	tact							
	0	NO	•						
	3				EU2B-YS2J10△	EU2B-YSK2J10△♦			
	0								
	②				EU2B-YS2J01△	EU2B-YSK2J01△◇			
	3	NC		•	LOZD TOZOTIZ	LOZD TORZOOT A			
	1	NO	•						
	2				EU2B-YS2J20△	EU2B-YSK2J20△♦			
	3	NO	•	•					
	① ②	NC		•	ELIOD VCO IOO A	ELIOD VOKO IOO A A			
O	3	NC		•	EU2B-YS2J02△	EU2B-YSK2J02△♦	C. Evnaged		
2-position	0	NO	•				C: Exposed screw terminal		
ď	2				EU2B-YS2J11△	EU2B-YSK2J11△♦			
	3	NC		•			F: Finger-safe		
°06	0	NO	•				screw terminal		
	3	NO	•		EU2B-YS2J30△	EU2B-YSK2J30△♦			
	0	NO NC	_	•					
	2	NC		•	EU2B-YS2J03△	EU2B-YSK2J03△◇			
	3	NC		•	LO2D 102000	LOZD TORZOOD			
	1	NO	•						
	2	NO	•		EU2B-YS2J21△	EU2B-YSK2J21△♦			
	3	NC		•					
	① ②	NO	•		ELIOD VCO HOA	FLIOD VOKO HO A A			
	3	NC NC			EU2B-YS2J12△	EU2B-YSK2J12△♦			

- ullet Specify a terminal style in place of \triangle in the Part No.
- C: exposed screw terminal), F: finger-safe screw terminal
- ullet Specify a key removable position code in place of \Diamond in the Part No. See the details at right.

Positions

(2-position, 2-position/inverse cam)

Selector Switch
Operator Position
Operator Position
Operator Position

R
Contact
Block
Position

Contact
Position

Selector Switch
Operator Switch
Operator Position
Operator

Key Removable Positions

(2-position, 2-position/inverse cam

(2-position, 2-	2-position, 2-position/inverse cam)											
: Key Removable Position												
A: key remov- able in all positions	B: key remov- able at left	C: key remov- able at right										
0 0	0 0	0 2										

①②: Key removable

● ②: Key retained

Selector Switches (3-position)

SU	Cont	act	Ор	era	tor				Pa	art No.			
을	Blo	ck	Po	siti	on		Selecto	r Switch			Key Selec	tor Switch	
No. of Positions	Mount- ing Posi- tion	Con- tact		0	2	Maintained L C R	Spring return from right	Spring return from left	Spring return two way	Maintained L C R	Spring return from right	Spring return from left	Spring return two way
	① ② ③	NO NO	•		•	EU2B- YS320∆	EU2B- YS3120△	EU2B- YS3220△	EU2B- YS3320△	EU2B- YSK320△◇	EU2B- YSK3120△◇	EU2B- YSK3220△◇	EU2B- YSK3320△◇
	① ② ③	NO NO	•		•	EU2B- YS320N1△	EU2B- YS3120N1△	EU2B- YS3220N1△	EU2B- YS3320N1∆	EU2B- YSK320N1△◇	EU2B- YSK3120N1△◇	EU2B- YSK3220N1△◇	EU2B- YSK3320N1△◇
	① ② ③	NC NC				EU2B- YS302∆	EU2B- YS3102△	EU2B- YS3202△	EU2B- YS3302△	EU2B- YSK302△◇	EU2B- YSK3102△◇	EU2B- YSK3202△◇	EU2B- YSK3302△◇
	① ② ③	NC NC		•		EU2B- YS302N1△	EU2B- YS3102N1△	EU2B- YS3202N1△	EU2B- YS3302N1△	EU2B- YSK302N1△◇	EU2B- YSK3102N1△♦	EU2B- YSK3202N1△◇	EU2B- YSK3302N1△♦
	① ② ③	NO NC	•			EU2B- YS311∆	EU2B- YS3111△	EU2B- YS3211△	EU2B- YS3311△	EU2B- YSK311∆♦	EU2B- YSK3111△◇	EU2B- YSK3211△◇	EU2B- YSK3311△◇
	① ② ③	NC NO			•	EU2B- YS311N1△	EU2B- YS3111N1△	EU2B- YS3211N1△	EU2B- YS3311N1△	EU2B- YSK311N1△◇	EU2B- YSK3111N1△◇	EU2B- YSK3211N1△◇	EU2B- YSK3311N1△◇
3-position	① ② ③	NO NC	•	•		EU2B- YS311N2△	EU2B- YS3111N2△	EU2B- YS3211N2△	EU2B- YS3311N2△	EU2B- YSK311N2△◇	EU2B- YSK3111N2△◇	EU2B- YSK3211N2△◇	EU2B- YSK3311N2△◇
ဗ	① ② ③	NC NO		•	•	EU2B- YS311N3△	EU2B- YS3111N3△	EU2B- YS3211N3△	EU2B- YS3311N3△	EU2B- YSK311N3△◇	EU2B- YSK3111N3△◇	EU2B- YSK3211N3△◇	EU2B- YSK3311N3△◇
	① ② ③	NO NC	•	•	•	EU2B- YS311N4△	EU2B- YS3111N4△	EU2B- YS3211N4△	EU2B- YS3311N4△	EU2B- YSK311N4△◇	EU2B- YSK3111N4△◇	EU2B- YSK3211N4△◇	EU2B- YSK3311N4△◇
	① ② ③	NO NO	•		•	EU2B- YS330△	EU2B- YS3130△	EU2B- YS3230△	EU2B- YS3330△	EU2B- YSK330△◇	EU2B- YSK3130△◇	EU2B- YSK3230△◇	EU2B- YSK3330△◇
	① ② ③	NC NC NC				EU2B- YS303∆	EU2B- YS3103△	EU2B- YS3203△	EU2B- YS3303△	EU2B- YSK303△◇	EU2B- YSK3103△◇	EU2B- YSK3203△◇	EU2B- YSK3303△◇
	① ② ③	NO NC NO	•	•	•	EU2B- YS321N1△	EU2B- YS3121N1△	EU2B- YS3221N1△	EU2B- YS3321N1△	EU2B- YSK321N1△◇	EU2B- YSK3121N1△◇	EU2B- YSK3221N1△◇	EU2B- YSK3321N1△◇
	① ② ③	NC NO NC	•		•	EU2B- YS312N1△	EU2B- YS3112N1△	EU2B- YS3212N1△	EU2B- YS3312N1△	EU2B- YSK312N1△◇	EU2B- YSK3112N1△◇	EU2B- YSK3212N1△◇	EU2B- YSK3312N1△◇


- Specify a terminal style in place of △ in the Part No. C: exposed screw terminal), F: finger-safe screw terminal
 Specify a key removable position code in place of ◇ in the Part No. See below for details.

Key Removable Positions (2-position)

♦: Key Removable Position								
A: key removable in all positions	B: key removable in right and center	C: key removable at center and right	D: key removable in center					
0 0 2	0 0	0 2	0 0 0					
E: key removable at left and right	G: key removable at left	H: key removable at right						
0 0 2	Q 9	0 0						

Spring return from right	Spring return from left	Spring return two-way
0 0	0 0 2	0 0

①①②: Key removable **①①②:** Key retained



Accessories


Plate Lock Padlock Cover

Shape	Part No.	Dimensions (mm)	Remarks
Material: SUS304	EU9Z-PC	32.1	Used for the following purposes. EU2B-YB2 extended pushbutton: to maintain latched status EU2B-YB1 flush pushbutton/EU2B-YSK key selector switch: to prevent operation

Pushbutton Cover

Shape	Part No.	Dimensions (mm)	Remarks
Material: SUS304	EU9Z-BC	60 (43)	 Used to protect the EU2B-YB push-button from inadvertent operation. Mounted by screwing on the control box and cannot be retrofit. Cannot be used for TIIS or UL/c-UL certified model.

Emergency Stop Switch Padlock Cover



Selector Switch Padlock Cover

Selector Switch			osition			
Shape	Part No.	-	3-position	Dimensions (mm)		Remarks
EU9Z-PC21	EU9Z-PCS21	Left	Left	60	(44.9)	
FILEZ POCC	EU9Z-PCS30	_	Center	60	(44.9) (44.9)	Used with EU2B-YS selector switch to maintain the switch in the selected lock status. Mounted by screwing on the
EU9Z-PC30	EU9Z-PCS22	Right	Right	60	20.5 (44.9)	control box and cannot be later. • Cannot be used for TIIS or UL/c-UL certified model.
Material: SUS304	EU9Z-PCS2X	Left Right	Left Right	60	(44.9)	

Pushbutton Rubber Boots

Shape	Part No.	Button Type	For use with nameplate	Rubber boot on pushbutton	Remarks
Material: Silicone rubber	EU9Z-DB1	Flush	No		
Material: Silicone rubber	EU9Z-DB1N	Flush	Yes	Flush pushbutton	 Used to protect the button of flush/extended pushbuttons.
Material: Silicone rubber	EU9Z-DB2	Extended	No		Cannot be used on TIIS certified models.
Material: Silicone rubber	EU9Z-DB2N	Extended	Yes	Extended pushbutton	

Control Box Shade

Chana	Part No.	Applicable Control Box	Di	mensions (m	m)
Shape	Part No.	Applicable Control Box	Н	W	D
	EC9Z-F2A21M	EC2B-11 B	180	160	160
	EG9Z-FZAZTIVI	EC2B-21 B	100	100	160
	EC9Z-F2A31M	EC2B-31 B	230	160	160
D > w	EC9Z-F2A51	EC2B-41 B	360	160	160
	EU9Z-FZA51	EC2B-51 B	360	160	100
H	EC9Z-F2A32	EC2B-22 B	260	420	160
	EG9Z-FZA3Z	EC2B-32 □ B			100
	EC9Z-F2A52	EC2B-42 B	360	420	160
		EC2B-52 B			
Material: stainless steel Thickness: 1mm	EC9Z-F2A33	EC2B-23 B	260	510	160
Photo: Part No. EC9Z-F2A52	EU9Z-FZA33	EC2B-33 □ B	200	310	100
	EC9Z-F2A53	EC2B-43 B	360	510	160
	EC9Z-FZA33	EC2B-53 B	300	310	100
	EC9Z-F2A63	EC2B-63 B	410	510	160
	EC9Z-F2A64	EC2B-64 B	410	580	160

- Protects control units from direct sunlight and rain.
- The surface of the control box shade is uncoated.
- Can be installed by tightening to the mounting tabs on the control box.
 Control box shade cannot be installed later. Specify shade at time of order.

Nameplates

Control Unit Nameplates

Shape	Part No.	Dimensions (mm)	Remarks
^	EU9Z-NM	40 Marking Plate (4.5)	Used for pilot light, pushbutton, selector switch, and key selector switch (only EU9Z-NP marking plates can be used on EU9Z-NM control unit nameplates).

Marking Plates for Control Unit Nameplates

Shape	Legend	Part No.
HAND OFF AUTO	Blank	EU9Z-NP0
ON	ON	EU9Z-NP1
OFF	OFF	EU9Z-NP2
START	START	EU9Z-NP3
	STOP	EU9Z-NP4
STOP	OFF-ON	EU9Z-NP31
Material: aluminum (35×6.5×1mm)	HAND-AUTO	EU9Z-NP35
(White legends on black background)	HAND-OFF-AUTO	EU9Z-NP53

[•] When other legends are needed, order blank nameplate and engrave.

Emergency Stop Switch Nameplate Sticker

			·	
Shape		Legend	Part No.	Dimensions (mm)
	1	Blank	EU9Z-NVS0	© ©
Material: synthetic paper Background: yellow Legend: black	2	EMERGENCY STOP	EU9Z-NVS27	040.5

Maintenance Parts

Lens

Shape	Color	Part No.
	Red	EU9Z-LR
	Green	EU9Z-LG
	Amber	EU9Z-LA
	Yellow	EU9Z-LY
	Blue	EU9Z-LS
	White	EU9Z-LW (*)

^{*} Used for W (white) and PW (pure white) illumination.

Buttons

Shape			Button Shape	Part No.	Button Color Code
1	2	3	① Flush	HW1A-B1□	Specify a color code in place of □ in the
			② Extended	HW1A-B2□	Ordering No. B: black S: blue
			③ ø40 Mushroom	HW1A-B4□	G: green W: white R: red Y: yellow

Control Unit Mounting Hole Plug

Shape	Part No.	Dimensions (mm)	Remarks
	EU9Z-BP	23.2 13.3 1.0 to 10.5 (panel thickness)	 Used to plug unused mounting holes (ø30.5) on the mounting panel. See page 24 for TIIS certified mountable control boxes. Not mountable on 1 contact block type of -GL, -U models.

TIIS Certified Models

Box	Control Unit	No. of Mountable Control Units								No. of	Control Unit	THO Time a Test
Size		PL	PB	ES	SS	M	BZ	(VR)	BP	Units	Terminal	TIIS Type Test Aproval No.
	01, 02	1	1	1			_	_	_	1	С	TC19254
11	01, 02	'	!	1	_						F	TC19255
''	06				1	_					С	TC19256
	00		_	_	'						F	TC19257
	01 02 10	2	2	2	_		_	1	_	2	С	TC19254
	01, 02, 10	2	2	2	_						F	TC19255
21	04	_	2	2	2						С	TC19256
21	04	_	2	2	2	_					F	TC19257
	06 17	2	_	_	2						С	TC19258
	06, 17	2	_	_	2						F	TC19259
31		3	3	3	3		_	_	_	3	С	TC19260
31		3	_ S	3	3	_					F	TC19261
41		4	4	4	4	1	1	_	3	4	C/F	TC19262
51		5	5	5	5	1	1	_	4	5	C/F	1019262
22		4	4	4	4	2	2	2	3	4	C/F	TC19263
32		6	6	6	6	2	2	2	5	6	C/F	10 19203
42	Δ	8	8	8	8	2	2	2	7	8	C/F	TC10064
52	Any	10	10	10	10	2	2	2	9	10	C/F	TC19264
23		6	6	6	6	3	3	3	5	6	C/F	TC10065
33		9	9	9	9	3	3	3	8	9	C/F	TC19265
43		12	12	12	12	3	3	3	11	12	C/F	TC10066
53		15	15	15	15	3	3	3	14	15	C/F	TC19266
63		18	18	18	18	3	3	3	17	18	C/F	TC19267
64		24	24	24	24	4	4	4	23	24	C/F	TC19268


PL: Pilot lights (EU2B-YL), PB: Pushbuttons (EU2B-YB), ES: Emergency stop switches (EU2B-YBV),

SS: Selector switches (EU2B-YS), Key Selector Switches (EU2B-YSK), M: Meter KS (EC9F-M), BZ: Buzzer (EC9F-Z),

VR: Variable resistor (EC9E-R), BP: Control unit mounting hole plug (EU9Z-BP), -: not mountable

TIIS Certified Models Part No. Development

These part numbers are marked on TIIS certificate and product label, and not ordering no.



Safety Precautions

- · Use explosion-proof electrical equipment that are applicable for use in hazardous areas (potentially explosive atmosphere where explosive gas or vapor may exist), otherwise explosion or fire hazard may result.
- EC2B control boxes can be installed only in zones 1 and 2. Do not use in zone 0. In North America, the EC2B can be installed in Division 2 areas, but cannot be installed in Division 1 areas.
- Turn power off to the EC2B control box before installation, removal, wiring, or maintenance, otherwise explosion, fire hazard, or electric shock may result.
- Special skills and knowledge of explosion protection, electric system installation, and relevant laws/regulations are required to transport, install, wire, operate, repair, and inspect the EC2B control box. People without such expertise must not use the EC2B control box, otherwise damage or accident may result.
- Do not modify the EC2B, otherwise damage or accident may result.
- Do not use a damaged EC2B control box, otherwise damage or accident may result.
- When connecting external devices, make sure that each cable is connected to the correct terminal, otherwise electric shock, fire hazard, or explosion may result.
- Use wires of a proper size to meet voltage and current requirements. Incorrect wiring may cause abnormal temperature rise and lead to fire hazard and explosion.
- Connect the grounding terminal to a proper ground, otherwise electric shock, fire hazard, or explosion may result.
- Do not sit on or hang from the EC2B control box, otherwise damage, personal injury, or accident may result.

- Do not open the lid of the EC2B control box when it is energized, otherwise electric shock, fire hazard, or explosion may result.
- Operate the EC2B control box at the rated current and voltage specified in this catalog, otherwise short-circuiting, fire hazard, or explosion may result.
- When measuring the insulation resistance of the EC2B control box, make sure that potentially explosive atmosphere of explosive gas or vapor does not exist in the vicinity, otherwise explosion may result. Also, do not touch the terminals without paying attention, otherwise electric shock will result.
- Do not place any obstacles in front of the nameplate.
- Do not remove the nameplate.
- When opening the lid for wiring, maintenance or inspection, make sure that substances such as dust, concrete powder, or metal powder do not enter inside the box, otherwise contact failure or insulation failure may result.
- Do not drop the EC2B control box during transportation.
- Be sure to open the carton the right way up, otherwise damage or personal injury may result.
- Check that the product is what you have ordered. Using an incorrect model might result in malfunction or acci-
- Stop operation immediately if abnormal operation occurs. Otherwise, a secondary accident may occur.
- The surface temperature of the EC2B control box may become extremely hot during operation. Before maintenance or inspection of the EC2B, be sure to wear gloves to prevent burning your hand.

Operating Instructions

- Notes on Use
- Installation Area
- Do not install the EC2B control box in an environment where more than IP65 protection degree (more than Type 4X in North America) is required.
- Use the EC2B control box under ambient temperature of -20 to +50°C. If the control box is exposed to direct sunlight and the surface temperature may rise above 50°C, provide a shade (see page 22) to keep the surface temperature below 50°C.
- Installation
- Wall mount
- Use four M6 bolts for 1-column, four M8 bolts for 2- and 3-column, or other methods with equivalent strength to install the control box. Mounting tab thickness is 1.5mm for 1 column and 2mm for 2, 3, and 4 columns. (See dimensions) (See dimensions.)
- Pole mount
 - Use four M12 bolts or other methods with equivalent strength to install the control box.
 - Use flat washers to prevent scratches on the pole base coating.

- If bolts become may loose due to vibration, use spring washers.
- If bolt corrosion is anticipated, use anti-corrosion bolts or other countermeasures.
- Notes on Emergency Stop Switches
- When using the emergency stop switches on safety-related parts of the control system, observe safety standards and regulations of the relevant country or region. Also be sure to perform a risk assessment before operation.
- Opening/Closing the Lid
- Use a Philips screwdriver to loosen lid mounting screws. While holding the unhinged side, open the lid slowly without exerting excessive force on the hinge.
- Before closing the lid, make sure of the following:
- No foreign substances are on the packing or joint sur-
- No displacement of the waterproof packing.
- Wires are not caught between the joint surfaces.
- · Next, close the lid slowly and tighten the screws to a proper torque of 1.6 to 2.4 N·m.

Operating Instructions

Limitation of the Operating Current

- Major heat sources comes from the wiring which is connected to the control box. Therefore, not only the operating current but wiring conditions (size, no. of wires, no. of wire bundles) may cause temperature rise. When wiring, observe the following conditions.
- · Stranded wire: 1.5 to 2.5 mm² (UL-c-UL certified) 1.25 to 2.5 mm² (other) solid wire: ø1.2 to ø1.6 mm (16 to 14 AWG)
- · Maximum no. of wires per bundle: 16
- · Maximum operating current: 10A
- When using the control box under operating environment of 40°C minimum, use a heat resistant cable of 70°C minimum.
- Determine the operating current so that the total heat value of 1 wire bundle is below 300 [A² × wires]. Also, when calculating the heat value, take the current fluctuation (10%) into consideration.

[calculation example: EC2B-41**B (8 circuit)]

 $\label{eq:poly}$ 10A to 1 circuit, 1A to the remaining 7 circuits:

 $\{(10A \times 1.1)^2 \times 2 \text{ wires}\} + \{(1A \times 1.1)^2 \times 14 \text{ wires}\} \approx 259$ (can be used because < 300)

②Apply 10A to 1 circuit, 2A to the remaining 7 circuits:

 $\{(10A \times 1.1)^2 \times 2 \text{ wires}\} + \{(2A \times 1.1)^2 \times 14 \text{ wires}\} \approx 310$ (cannot be used because > 300)

2. See the table below for the allowable operating current when applying current evenly to each control box.

Control Box Part No.	Max. No. of Circuits	Max No. o Bund [wires] ([wire	Allowable Operating Current				
rait No.		Without terminal blocks	With terminal blocks	(reference) (*2)			
EC2B-11 B	3	16 (16×1)	8 (8×1)	7A			
EC2B-21 B	6	16 (16×1)	8 (8×1)	5A			
EC2B-31 B	9	16 (16×1)	8 (8×1)	4A			
EC2B-41 □ B □	12	16 (16×1)	16 (16×1)	3A			
EC2B-51 B	15	16 (16×1)	16 (16×1)	3A			
EC2B-22□B□	12	32 (16×2)	16 (8×2)	5A			
EC2B-32□B□	18	32 (16×2)	16 (8×2)	4A			
EC2B-42□B□	24	32 (16×2)	32 (16×2)	3A			
EC2B-52□B□	30	32 (16×2)	32 (16×2)	3A			
EC2B-23 B	18	48 (16×3)	24 (8×3)	5A			
EC2B-33□B□	27	48 (16×3)	24 (8×3)	4A			
EC2B-43□B□	36	48 (16×3)	48 (16×3)	3A			
EC2B-53□B□	45	48 (16×3)	48 (16×3)	3A			
EC2B-63□B□	54	48 (16x3)	48 (16x3)	3A			
EC2B-64□B□	72	64 (16x4)	64 (16x4)	3A			

- *1: Make sure that the number of wires per bundle is a maximum of 16 by reducing the wiring or by jumper wiring. The maximum number of wires per bundle may need to be further reduced depending on the wire size, lead-in fitting, or conduit size.
- *2: The allowable current value (reference) when applying current evenly to all circuits of the maximum number of circuits.

Wiring Construction

- Observe the laws and regulations in each country concerning wiring construction.
- Use cable wiring or metal conduit wiring for installation in hazardous locations. If foreign objects or water may enter the box, install a sealing fitting near the cable entry of the box and seal the control box using a compound.
- Standard type control boxes do not contain a terminal block. Wire the control units directly.

Operating Instructions

Wiring

Applicable Wires


Stranded wire: 1.25 to 2.5 mm 2 , solid wire: \emptyset 1.2 to \emptyset 1.6 mm (AWG16 to 14)


• Do not connect more than 2 wires to the same terminal.

Applicable crimping terminal


- Ring terminals cannot be used for EU2B control units with IP20 finger-safe terminals.
- Ring and spade terminals cannot be used for IP20 clamp type terminal blocks.
- When connecting 2 ferrules to an EU2B control unit, use ferrules without insulating sheath.

For control units EU2B







For control units EC9



For screw terminal ET2A-8PE For IP20 clamp terminal






Recommended crimping terminal (WAGO)
 Ferrule with insulating sheath: 216-204
 Ferrule without insulating sheath: 216-104
 Crimping plier: 206-204

Recommended Tightening Torque

EU2B control units (M3.5) and ET2A-8PE terminal block (M4): 1.0 to 1.3 N·m

Warning

Incorrect wiring may cause fire hazard. Observe the following conditions.



- Be sure to install an insulating sheath on the crimping terminal or the crimping terminal with insulation.
- When connecting solid wires or stranded wires directly, strip the insulation as mentioned below, and insert the wire all the way in.

EU2B Control units: 8.6 mm maximum IP20 crimping terminal: 8 to 9 mm

- When using stranded wires, make sure that there are no wire whiskers.
- Make sure that the spade crimping terminals and ferrules are inserted all the way in.
- Use insulated ring terminals for the ET2A-8PE terminal block. Use only applicable crimping terminals and do not directly connect stranded wires or solid wires.

Operating Instructions


Removing and Installing the Contact Unit/ Lamp Unit

Removing the Contact Unit/Lamp Unit

To remove the contact unit or the lamp unit from the operator, pull the protruding part of the locking lever outwards as shown in the figure below (using a screwdriver, etc.) and turn it to the left. The contact unit or lamp unit can be pulled out.

Emergency stop switch


Note that when contact unit is detached from the operator part, the NO contact is closed and NC contact is open. Do not move the lock lever when the contact unit is detached (red indicator is protruded), otherwise the switch will be damaged.



Installing the Contact Unit/Lamp Unit


To install the contact unit, place the TOP marking on the operator and the TOP marking on the contact block adaptor in the same direction, and then attach the contact unit to the operator as shown in the figure below. Then turn the locking lever to the right. Follow the same procedure when installing the lamp unit.

 When installing the lamp unit, check that the inner lens is not loose. Note that the contact units of the emergency stop switch and pushbutton/selector switch are not interchangeable.



Removing the Contact Block

To remove the contact block, insert a flat screwdriver under the latch of the contact block adaptor and disengage the latch as shown in the figure below.



When installing the contact block after mainte-

nance or wiring, make sure that the contact configuration is correct. Installing the contact block in an incorrect position or incomplete installation may cause malfunction of the switch.

Make sure to remove the contact block from the operator before installing the contact block to the contact block adaptor. Also make sure that the contact block is correctly installed to the contact block adaptor before attaching the operator. Do not install the contact block adaptor with the operator attached. Otherwise, malfunction may result.

Protective Grounding

Protective grounding must be performed according to the installation environment and rating requirements. Observe laws and regulations set by each country.

- Connect the M4 grounding terminal of the EC2B control box to a proper ground (grounding resistance 10Ω maximum). When operating the EC2B control box by connecting to circuits of 300V or below, the grounding resistance must be 100Ω maximum.
- When using cables, connect one of the cable cores to the grounding terminal in the enclosure.
- If the grounding terminal in the enclosure cannot be used, use the M4 grounding terminal on the outside of the enclosure for wall mount, or the M6 grounding terminal of the pole base for pole mount.
 Recommended tightening torque:

M4: 1.0 to 1.3 N·m M6: 3.9 to 5.4 N·m

For grounding, use appropriate wires (size, material, insulation) that can tolerate the expected maximum grounding current. Be sure to protect the grounding wire with protection, such as metal conduit, from external damage.

Maintenance and Inspection

- Observe laws and regulations set by each country.
- Do not open the lid when inspecting the EC2B while it is energized.
- Never disassemble the control box.
- Do not use tools that cause sparks during maintenance and inspection.
- When using measuring devices, use explosion-protected types.
- When the EC2B needs to be disassembled or assembled for maintenance or repair, contact IDEC.

Disposal

Observe laws and regulations set by each country concerning refuse disposal.

ΙП	Œ	C
ıv		•

EC2B

TO: IDEC Corporation

1-column Control Box Specification Sheet

No. of Control Box

Company:								
Contact Pe	rson:	FAX:						
Select the required specifications by checking the checkboxes (\checkmark), and specify the details.								
1. Certification	☐ IECEx/A	TEX/Ex-CCC UL/c-UL, IECEx/ATEX						
2. Control box size (wa	2. Control box size (wall mount only)							
□ EC2B-110	□ EC2B-210	0 □ EC2B-310 □ EC2B-410 □ EC2B-510						
		NP NP						
Nameplate NP 1 E1	(1) (2) (2)	1 (1) (2) (3) (4) (6) (2) (2) (4) (5) (2) (4) (6) (2) (4) (6) (4) (6) (4) (6) (4) (6) (6) (6) (6) (6) (6) (6) (6) (6) (6						
	terial: Acrylic (53 mm ×	x 12 mm, plate thickness 2 mm)						
		9 letters per line (up to 2 lines)						
☐ No ☐ 1 lin nameplate	е	1st line 2 lines 2 lines 2 lines 2 line 3 line 2 line 3 line 2 line 3 line 2 line 3 li						
4. Control Units								
	Unit Part No.	Control Unit Nameplate						
_		□ ON □ OFF □ START □ STOP □ EMERGENCY STOP						
		□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank						
		□ No nameplate □ Specify letters ()						
2		□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank						
		□ No nameplate □ Specify letters ()						
		□ ON □ OFF □ START □ STOP □ EMERGENCY STOP						
3		☐ OFF ON ☐ HAND AUTO ☐ HAND OFF AUTO ☐ Blank						
		□ No nameplate □ Specify letters ()						
		□ ON □ OFF □ START □ STOP □ EMERGENCY STOP □ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank						
(4)		□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank □ No nameplate □ Specify letters ()						
5		□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank						
		□ No nameplate □ Specify letters ()						
5. Wall Mount Lead-in		EC2B-110, 210, 310 EC2B-410, 510						
Fitting (E1/E2)	IECEx/ATEX/Ex-CCC of							
Without specification	UL/c-UL, IECEx/ATEX							
(standard reducer)	EC2B-110, 210, 310	EC2B-410, 510						
	Code Cable lead-in meth							
		☐ M16 ☐ M25						
		□ M20 □ M32						
	E1 Reducer	□ M25 □ M40						
With specification								
		□ NPT 1/2 □ Reducer □ NPT 1 □ NPT 3/4 □ NPT 1 1/4						
		□ NPT 3/4 □ NPT 1 □ G3/4 (22)						
		G1/2 (16) G1 (28)						
		G3/4 (22) G1 1/4 (36)						
		G1 (28) * G thread is not available on UL/c-UL, IECEx/ATEX certified.						

TO: IDEC	Corporation		(/)	EC2			fied Model Decification Sheet
	Company:				TEI	<u>.</u> :		No. of Control Box
	Contact Pe				FAX			
Oalaat III.aaaa								
	uired specifications					e details.		
1. Mour	iting method	□ Wall r	mount		e mount			
	ol box size EC2B-110	□ EC2B-	-210		C2B-310) □ EC2I		□ EC2B-510
	Nameplate 1 E1	1	E1		1 (2) (3) E1			(1) (2) (3) (4) (5) (1) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4
☐ No	plate (III) Le	aterial: Acrylic (53 n gend color: black l aximum no. of lette	etter, white	backgroun	nd	1st line		
4. Contr	ol Units							
Pos	ition Control U	Jnit Part No.				Control Unit Namep	late	
				□ ON □ OFF C		☐ START D AUTO ☐ HAND (☐ Specify letters (□ STOP OFF AUTO	☐ EMERGENCY STOP☐ Blank)
	2			□ ON □ OFF C		☐ START D AUTO ☐ HAND (☐ Specify letters (□ STOP OFF AUTO	☐ EMERGENCY STOP☐ Blank)
	3)			□ ON □ OFF C		☐ START D AUTO ☐ HAND (☐ Specify letters (□ STOP OFF AUTO	□ EMERGENCY STOP □ Blank)
	Ð			□ ON □ OFF C □ No nan		☐ START D AUTO ☐ HAND (☐ Specify letters (□ STOP OFF AUTO	☐ EMERGENCY STOP☐ Blank)
(5)			□ ON □ OFF C		☐ START D AUTO ☐ HAND (☐ Specify letters (□ STOP OFF AUTO	□ EMERGENCY STOP □ Blank)
5. Wall Mount Lead-in Fitting (E1/E2) (Specification is not necessary for pole mount) • G3/4 screw (22) reducer is used for EC2B-110, 210, 310 types. • G1 screw (28) reducer is used for EC2B-410, 510 types. • Standard reducer is used if unspecified.								
	B-110, 210, 310	nod Check	Cnocific-t	ion	EC2B-41	•	Check	Charification
	ode Cable lead-in meth	Crieck	Specificat G1/2 (16		Code	Cable lead-in method	П	Specification G3/4 (22)
	Reducer (metal conduit) 🔲	G3/4 (22			Reducer (metal conduit)		G1 (28)
			G1 (28) ø6 to ø8					G1 1/4 (36) Ø12 to Ø14
F	:1		Ø8 to Ø1		E2			Ø14 to Ø16
'	Flameproof pack		ø10 to ø	12		Flameproof packing		Ø16 to Ø18
	cable lead-in fitti (cable)	ng 🔲	Ø12 to Ø1			cable lead-in fitting (cable)		Ø18 to Ø20
	(Subic)							Ø20 to Ø23
			Ø16 to Ø2			-	<u> </u>	Ø23 to Ø26
			שוסוט שוש	20		The value	ues in () indica	te the nominal sizes.

BGLEN01A EC2B December 2022

Ordering Terms and Conditions

Thank you for using IDEC Products.

By purchasing products listed in our catalogs, datasheets, and the like (hereinafter referred to as "Catalogs") you agree to be bound by these terms and conditions. Please read and agree to the terms and conditions before placing your order.

1. Notes on contents of Catalogs

- (1) Rated values, performance values, and specification values of IDEC products listed in this Catalog are values acquired under respective conditions in independent testing, and do not guarantee values gained in combined conditions.
 - Also, durability varies depending on the usage environment and usage conditions.
- (2) Reference data and reference values listed in Catalogs are for reference purposes only, and do not guarantee that the product will always operate appropriately in that range.
- (3) The specifications / appearance and accessories of IDEC products listed in Catalogs are subject to change or termination of sales without notice, for improvement or other reasons.
- (4) The content of Catalogs is subject to change without notice.

2. Note on applications

- (1) If using IDEC products in combination with other products, confirm the applicable laws / regulations and standards.
 - Also, confirm that IDEC products are compatible with your systems, machines, devices, and the like by using under the actual conditions. IDEC shall bear no liability whatsoever regarding the compatibility with IDEC products.
- (2) The usage examples and application examples listed in Catalogs are for reference purposes only. Therefore, when introducing a product, confirm the performance and safety of the instruments, devices, and the like before use. Furthermore, regarding these examples, IDEC does not grant license to use IDEC products to you, and IDEC offers no warranties regarding the ownership of intellectual property rights or non-infringement upon the intellectual property rights of third parties.
- (3) When using IDEC products, be cautious when implementing the following.
 - i. Use of IDEC products with sufficient allowance for rating and performance
 - Safety design, including redundant design and malfunction prevention design that prevents other danger and damage even in the event that an IDEC product fails
 - Wiring and installation that ensures the IDEC product used in your system, machine, device, or the like can perform and function according to its specifications
- (4) Continuing to use an IDEC product even after the performance has deteriorated can result in abnormal heat, smoke, fires, and the like due to insulation deterioration or the like. Perform periodic maintenance for IDEC products and the systems, machines, devices, and the like in which they are used.
- (5) IDEC products are developed and manufactured as general-purpose products for general industrial products. They are not intended for use in the following applications, and in the event that you use an IDEC product for these applications, unless otherwise agreed upon between you and IDEC, IDEC shall provide no guarantees whatsoever regarding IDEC products.
 - i. Use in applications that require a high degree of safety, including nuclear power control equipment, transportation equipment (railroads / airplanes / ships / vehicles / vehicle instruments, etc.), equipment for use in outer space, elevating equipment, medical instruments, safety devices, or any other equipment, instruments, or the like that could endanger life or human health
 - Use in applications that require a high degree of reliability, such as provision systems for gas / waterworks / electricity, etc., systems that operate continuously for 24 hours, and settlement systems
 - iiii. Use in applications where the product may be handled or used deviating from the specifications or conditions / environment listed in the Catalogs, such as equipment used outdoors or applications in environments subject to chemical pollution or electromagnetic interference If you would like to use IDEC products in the above applications, be sure to consult with an IDEC sales representative.

3. Inspections

We ask that you implement inspections for IDEC products you purchase without delay, as well as thoroughly keep in mind management/maintenance regarding handling of the product before and during the inspection.

4. Warranty

(1) Warranty period

The warranty period for IDEC products shall be one (1) year after purchase or delivery to the specified location. However, this shall not apply in cases where there is a different specification in the Catalogs or there is another agreement in place between you and IDEC.

(2) Warranty scope

Should a failure occur in an IDEC product during the above warranty period for reasons attributable to IDEC, then IDEC shall replace or repair that product, free of charge, at the purchase location / delivery location of the product, or an IDEC service base. However, failures caused by the following reasons shall be deemed outside the scope of this warranty.

- i. The product was handled or used deviating from the conditions / environment listed in the Catalogs
- ii. The failure was caused by reasons other than an IDEC product
- iii. Modification or repair was performed by a party other than IDEC
- iv. The failure was caused by a software program of a party other than IDEC
- v. The product was used outside of its original purpose
- Replacement of maintenance parts, installation of accessories, or the like was not performed properly in accordance with the user's manual and Catalogs
- vii. The failure could not have been predicted with the scientific and technical standards at the time when the product was shipped from IDFC
- viii. The failure was due to other causes not attributable to IDEC (including cases of force majeure such as natural disasters and other disasters)
 Furthermore, the warranty described here refers to a warranty on the IDEC product as a unit, and damages induced by the failure of an IDEC product are excluded from this warranty.

5. Limitation of liability

The warranty listed in this Agreement is the full and complete warranty for IDEC products, and IDEC shall bear no liability whatsoever regarding special damages, indirect damages, incidental damages, or passive damages that occurred due to an IDEC product.

6. Service scope

The prices of IDEC products do not include the cost of services, such as dispatching technicians. Therefore, separate fees are required in the following cases.

- (1) Instructions for installation / adjustment and accompaniment at test operation (including creating application software and testing operation, etc.)
- (2) Maintenance inspections, adjustments, and repairs
- (3) Technical instructions and technical training
- (4) Product tests or inspections specified by you

The above content assumes transactions and usage within your region. Please consult with an IDEC sales representative regarding transactions and usage outside of your region. Also, IDEC provides no guarantees whatsoever regarding IDEC products sold outside your region.

IDEC CORPORATION

d Office 6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

Singapore

Thailand

IDEC Izumi Asia Pte 1 td

IDEC Asia (Thailand) Co., Ltd.

www.idec.com

India IDEC Controls India Private Ltd.

IDEC Izumi (H.K.) Co., Ltd. **Taiwan** IDEC Taiwan Corporation

IDEC (Shanghai) Corporation

China

IDEC

IDEC Corporation

IDFC Corporation

APEM SAS

IISΔ

EMEA